

VERSIV JUMBO/JUMBO PLUS

SCREW HOLE SEQUENCE

Example shown with 3.5
Jumbo Plate Item #: ETC-35JR

1 CORTICAL SCREW
Partially tightened

2 LOCKING SCREW
Fully tighten

3 LOCKING SCREW
Fully tighten

4 LOCKING SCREW
Fully tighten

5 CORTICAL SCREW
Compression Slot
Fully tighten

6 LOCKING or CORTICAL SCREW
For Additional Compression
Fully tighten

7 LOCKING SCREW
Fully tighten

LOCKING SCREW
Fully tighten

LOCKING SCREW
Fully tighten

LOCKING SCREW
Fully tighten

LOCKING SCREW
Fully tighten

Use a
STA-FIX pin
distally for
temporary
fixation



Note: The screw sequence is a recommended guide only.
In certain situations, this exact sequence may not be able to be executed.

©2024 Movora

VERSIV 3.5 BROAD

SCREW HOLE SEQUENCE

1 CORTICAL SCREW
Partially tightened

2 LOCKING SCREW
Fully tighten

3 LOCKING SCREW
Fully tighten

4 LOCKING SCREW
Fully tighten

5 CORTICAL SCREW
Compression Slot
Fully tighten

6 LOCKING or CORTICAL SCREW
For Additional Compression
Fully tighten

LOCKING SCREW
Fully tighten

LOCKING SCREW
Fully tighten

LOCKING SCREW
Fully tighten

Use a
STA-FIX pin
distally for
temporary
fixation



Note: The screw sequence is a recommended guide only.
In certain situations, this exact sequence may not be able to be executed.

MMKT-SS-0059-A